









## COX® Base Electric Opener




44011487\_00

1







ø 10 mm



2




1





**3**

4 x  
4,5 x 16 mm



4 x  
4,5 x 16 mm




4









2



5.0




# 5



# 6



ø 5 mm



7



1

